OPERATING MANUAL

Transducer for AC Current RishCON-I11



Operating Instructions

Contents

 Read first and then 	
Brief Description	
3. Product Features	3
Overview of the Parts	4
Scope of supply	5
6. Technical Data	5
Mounting	9
8. Electrical Connections	
Commissioning	
10. Dimensional Drawings	13
11. Ordering Information	14

1. Read first and then



The proper and safe operation of the device assumes that the Operating Instructions are read and the safety warnings given in the various sections Mounting, Electrical connections, Commissioning are observed.

All operations concerning installation, electrical connections and commissioning, must be carried out by qualified, skilled personnel, and national regulations for the prevention of accidents must be observed.

2. Brief Description

The Transducer converts a sinusoidal AC Current or Voltage into Two load independent DC Current or a load independent DC Voltage proportional to the measured value.

The transducer outputs are galvanically isolated from the input signal and auxiliary supply.

3. Product features

Arithmetical mean value measurement Calibration to RMS with sine waveform (Average Value)

Accuracy class 0.5

as per International Standard IEC/EN 60 688.

Isolated DC current or DC voltage outputs.

Output Response Time < 200 ms.

Fast and easy installation on DIN RAIL or onto a wall or in panel using optional screw hole bracket.

Connection Terminal: Conventional Screw type.

4. Overview of the parts

Figure 1 shows those parts of the device which are used for mounting, electrical connections and other operations described in the Operating instructions.



Fig. 1: Overview of the Transducer parts

- (1) Fixing Bracket
- (2) Front sticker
- (3) Input Terminals
- (4) Output Terminals
- (5) Red LED for Power ON indication.
- (6) Not Connected Terminals (NC).

5. Scope of Supply

The set of the Transducer consist of :



Fig. 2: Transducer Set

6. Technical Data

Current Transducer (RishCON - I11)

Final value of Nominal Input	1A, 5A, {1.3A and 6.5A (On request)}.			
Current IN (X2) AC RMS				
Nominal Frequency F _N	50 or 60Hz			
Nominal Input Current Burden	Full O/p value [mA] [VA]			
	1	<0.8VA at IN		
	5	<1.8VA at IN		
	10	<2.2VA at IN		
	20	<2.5VA at IN		

Overload Capacity	
1.5*IN	Continuously,
2*IN	for 10 second, repeated 10 times at
	10 second intervals,
10*IN	for 3 second, repeated 5 times at
	5 minute intervals,
40*IN	for 1 second, 1 time.

Note: Overload not applicable for input range 1.3A and 6.5A

Measuring Output Y: Output type Load independant DC current IA or DC voltage output VA Load independent 0 1/0 5/0 10/0 20 mA DC current 4 20 mA Output range Output burden with R...max. [kΩ] = 15 VA/IAN [mA] DC current output signal [IAN = full output value] DC voltage output range Output VA not superimposed : std range of VA: 0...10V Rext ≥ 200kQ/V Output burden with DC current output signal Current limit under overload ≤1.5 * IAN for current output Approx. 30 mA for voltage Voltage limit under Rext = ... <24 V Residual Ripple in output signal Current Ripple ≤1%p.p. Response time <200ms Output standard ranges Current : 0...1/0...5/0...10/0...20 mA Voltage : 0-10V 12-30V (only for 2-wire connection with DC power supply output 4...20mA)

Accuracy(Acc. to IEC/EN 60 688) Accuracy Class 0.5

Reference conditions for Accuracy

Ambient temperature Pre-conditioning Input variable

Input signal frequency Distortion factor Output load

Power Supply Infiuence Effects (maxima) : Linearity error Frequency Dependances on

external resistance

Additional Errors

Temperature influence Curve shape of Input Frequency of input variable Influence of Variations 23°C,± 5k ≤5 min. 0 to 100% for current measurement 20 to 100% for voltage 50...60Hz ± 2% < 0.5% Current output: 0 - Rext Max. Voltage output: Rext Max to ∞ ± 1% for 24Vdc with 4...20mA output.

< ± 0.3% ± 0.3% (Fn ± 0.2%)

± 0.1% A Rext Max

± 0.2% /10°C. Sine waveform only 45...200Hz ± 0.5% As per IEC/EN 60 688 standard.

Output characteristics:









Fig. 5

Standard ranges of IA = 4...20mA, External Resistance Rext dependent on power supply H(12...30V DC)



Variable Sensitivity and live zero.



Characteristics A "Standard"



Fig. 9 Characteristics A "Standard Variable Sensitivity". E3 ±5% or ±10%

Safety:	
Protection Class	II (Protection Isolated, EN 61 010)
Protection	IP 40, housing according to EN 60 529
	IP 20 ,terminal according to EN 60 529
Pollution degree	2
Insulation Voltage	7750VDC, Input versus outer surface
	7750VDC, Output versus outer surface
	5500VDC, Input versus output.
Installation Data:	
Mechanical Housing	Lexan 940 (polycarbonate)
	Flammability Class V-0 acc. To UL 94,
	self extinguishing, non dripping, free of
	halogen
Mounting position	Rail mounting / wall mounting
Weight	Approx. 0.5Kg
Connection Terminal:	
Connection Element	Conventional Screw type terminal with
	indirect wire pressure
Permissible cross section	\leq 4.0 mm ² single wire or 2 x 2.5 mm ²
of the connection lead	fine wire
Environmental:	
Nominal range of use	-25 °C <u>23 °C</u> 55 °C (usage Group II)
Storage temperature	-40 °C to 70 °C
Relative humidity of	≤ 75%
annual mean	≤ 90% Enhanced Climatic Rating
Altitude	up to 2000 m
Ambient tests:	
IEC 60 068-2-6	Vibration
Acceleration	± 2 g
Frequency range	1015010Hz,
Rate of frequency sweep	1 octave/minute
Number of cycles	10, in each of the three axes
IEC 60 068-2-27	Shock
Acceleration	3 x 50g
	3 shocks in each direction

7. Mounting

The Transducer can be mounted either on a top-hat rail or directly onto a wall or mounting plate.





As the front of the enclosure conforms to IP 40. The terminals of the product should be protected from liquids. Transducer should be mounted in a reasonably stable ambient temperature and where the operating temperature is within the range 0 to 45°C. Vibration should be kept to a minimum and the product should not be mounted where it will be subjected to excessive direct sunlight.

Caution

1. In the interest of safety and functionality this product must be installed by a qualified engineer, abiding by any local regulations.

 Voltages dangerous to human life are present at some of the terminal connections of this unit. Ensure that all supplies are de-energised before attempting any connection or disconnection.

3. These products do not have internal fuses therefore external fuses must be used to ensure safety under fault conditions.





Drill 2 holes in the wall or panel as shown in the drilling plan (Fig. 3). Now secure the wall mounting holder to the wall or panel using two 4 mm diameter screws.

8. Electrical connections

Input connections are made directly to screw-type terminals with indirect wire pressure. Choice of cable should meet local regulations. Terminal for Current inputs will accept up to 4.0 mm² single wire or 2 x 2.5 mm² fine wire.



Make sure that the cables are not live when making the connections !

Connection	Terminal details		
Measuring input	2 2	5 6	
Measuring output	+	1 2	
Not Connected	NC	3,4,7,8	





Switch on the measuring inputs. The Red LED light continuously ON after switching on.

10. Dimensional drawings

Note : All Dimensions are in mm.



Ordering information

Product Code	CA11	Х	XX	XX	00000000
Model	AC CURRENT TRANSDUCER Class 0.5	А			
Input Current range	Fixed Input 01A		11		
	Fixed Input : 05A		51		
Output	0 10mA			01	
	0 5mA			02	
	0 20mA			03	
4 20mA			04		
	010V			05	

Notes

Notes