

# RISH Clamp-on CT 1000/1A, CT 1000/5A, CT 300/0.3A

## Clamp-on CT for AC current measurement

### Data Sheet

Clamp-on CT for AC current measurement



**Rish clamp on CT 300 A / 0.3A**

*RISH Clamp* -on CT 300 A should be used as accessories for RISH Multi 12s which directly displays the Current in 300 A range.



**Rish clamp on CT 1000/ 5A**

*RISH Clamp* -on CT 1000 A should be used as accessories for RISH Multi series.



**Rish clamp on CT 1000 A / 1A**

*RISH Clamp* -on CT 1000 A should be used as accessories for RISH Multi series.

## Application

**Rish Clamp**-on CT 300 A / 1000A measures current without interrupting the conducting line. They are used for electrically isolated measurement of alternating current within a broad range ,without interrupting the current conducting cable and bus bars.

## Features of Rish Clamp on CT 300 A/ CT 1000 A

- Safety in accordance with IEC 61010-1.
- Minimum transformation ratio error.
- Compact, handy design.
- Permanently connected safety cables.

## Measurement

**Rish Clamp** on CT measures AC current without interrupting the conducting line. The opening contact of both the core which become visible when trigger is pressed, must be always kept clean. Even small outside particles can deviate measuring accuracy. The measuring secondary long cables with contact- protected connection plugs, which electrically isolates the measurement of AC current without interruption.

## Specifications

Clamp on current transformer			
Type	CT 1000A / 1A	CT 300A / 0.3A	1000A /5A
Description/ Application	The current transformers are used for electrically isolated measurement of alternating current within broad range.It is possible to measure AC current without interrupting the current conducting cable and bus bars via hard wired leads with contact protected plugs.		
Nominal Primary Current	1-1000 A AC	4-300 A AC	1-1000 A AC
Output signal	1mA AC / A AC	0.3 mA AC / A AC	1mA AC / A AC
Used with	Rish multi series	Rish multi 12s	Rish multi series
Transmission ratio Input:Output	1000:1	1000:1	200:1
Accuracy / max.error	Class 1 (2.5 VA) (for current range from 1A to 1000A, 50Hz)	Class 1 ( 1.25 VA) (for current range from 4A to 300A, 50Hz)	Class 1 (2.5 VA) (for current range from 1A to 1000A, 50Hz)
Max. operating Voltage	CAT III 600 V as per IEC-61010	CAT III 600 V as per IEC-61010	CAT III 600 V as per IEC-61010
Frequency range	40Hz....1kHz	40Hz....1kHz	40Hz....1kHz
Jaw opening / Conductor Diameter	43mm / Diameter 43mm	35mm / Diameter 35mm	43mm / Diameter 43mm
Dimensions (W X H X D)	( 92 X 39 X 220) mm	(84 X 39 X 202)mm	( 92 X 39 X 220) mm
Weight	Approx 650 gms	Approx 500 gms	Approx 650 gms
Cable length	1.5 meter	1.5 meter	1.5 meter

## Periodic Check-up

The clamp on CT does not require any specific maintenance. While cleaning, the probes must not be immersed into any liquid. No special maintenance is required for housing. The surface between the opening jaws should be cleaned with dry cloth before operating. Avoid use of cleansers, abrasives or solvents.

## Safety Features & Precautions



- Application around & removal from HAZARDOUS LIVE conductor is permitted

The Rish Clamp on current transformers are constructed with safety rules of IEC 61010-1. When in operation the safety of user and unit is assured. Also when the secondary circuit is interrupted, the Clamp has a Protection circuit which prevents high voltage to be generated. Before operating read completely the instruction manual. These instruction must be followed by users in all respects. In case of incorrect use or careless handling, the safety of both user and clamp is not assured.



[www.rishabh.co.in](http://www.rishabh.co.in)

**RISHABH**  
INSTRUMENTS  
Measure, Control & Record with a Difference

**RISHABH INSTRUMENTS PVT.LTD.**  
F-31, MIDC, Satpur, Nashik-422 007, India.  
Tel.: +91 253 2202160, 2202202 Fax : +91 253 2351064  
E-mail : India :- marketing@rishabh.co.in  
International :- exp.marketing@rishabh.co.in  
[www.rishabh.co.in](http://www.rishabh.co.in)